

XLS 21 & CompuTime101- Quick Setup Guide v1.3

CompuTime101 Software Setup Overview

Default Software Login: *User Name = Admin Enter Password = Password*

Recommended order of software setup:

- 1) Enter Upgrade Codes (if applicable) (*File→Software Utilities→Enter Upgrade Code*)
- 2) Setup global rules (*Edit→Edit Global Company Rules*)
- 3) Define Clock Sites (*Edit→Edit Clocks*) (refer to [Configuring Communication](#) section below for more details)
- 4) Define Departments (if applicable, a default department is already defined) (*Edit→Edit Departments*)
- 5) Define Shift Rules if applicable (*Edit→Edit Shift Rules*)
- 6) Enter Employees (*Edit→Edit Employees*)

Detailed CompuTime101 Software User's Guides are available from the Help menu of the software and Online at <http://support.computime101.com/>

XLS 21 Clock Setup

Configuring Communication

If Using RS232 Serial:

Note: Please refer to the enclosed connection guide for a cable connection diagram

Note: RS232 serial communication does not require any setting changes at the clock.

- In the software select *Edit Clocks* from the *Edit* menu at the top menu bar
- A sample clock site is pre-configured for RS232 communication on Com Port 1 (If no site is defined, number the site 1 and press enter). To define an additional clock site, click the right arrow to move to a new record, enter the new site number, and press enter.
- Select Pin/Prox/Fingerprint as the model and RS232 as the communication style. If you know the COM Port number, enter it. If not, double click where the COM Port number should be and select yes to have the software auto detect.
- You can test the communication by clicking "Test" in the Edit Clocks window.

If Using TCPIP Ethernet:

Note: Please refer to the enclosed connection guide for a cable connection diagram

Note: Connect the clock to the network/router, not directly to the computer's Ethernet port.

- In the software select *Edit Clocks* from the *Edit* menu at the top menu bar
- A sample clock site is pre-configured for RS232 communication on Com Port 1 (If no site is defined, number the site 1 and press enter). To define an additional clock site, click the right arrow to move to a new record, enter the new site number, and press enter.
- Select Pin/Prox/Fingerprint as the model and TCP/IP as the communication style. Enter the IP address of the clock (the default IP address is 192.168.1.201) and click the *Test* button to verify the connection. If you receive a "Comm Test OK" message you are done with this section, otherwise continue to the next step for advanced IP configuration.

----- Advanced IP configuration:

- Click the yellow question mark next to the IP address box to check the IP of your computer and receive a suggested IP address to use for the clock. Enter the suggested IP in the address box then go to the clock terminal to change the IP address (in the following menu section):

Menu→Options→Comm Opt→(IP Addr)

Note: The (NetMask) and (Gateway) settings are also required if connecting through a VPN or Port Forward

Once the correct IP has been entered into both the clock and the software, click the Test button in the software to verify the connection.

Using A USB Thumb Drive (aka Flash Drive):

Note: When using a USB Thumb Drive (aka Flash Drive) the software does not directly communicate with the clock.

- Connect the thumb drive to the clock using the small adapter cable (included with the thumb drive purchase)
- To download the punch data (aka attendance log) at the clock terminal go to **Menu→PenDriveMng→DwnLoad AttLog**

Note: If an Administrator is enrolled in the clock, Supervisor rights are required to access this menu

You should receive the message "Copy Data Suc". You may then press ESC to exit the menu and then unplug the drive.

- To Process (aka import) the punches (aka attendance data) into the CompuTime101 software first plug the thumb drive into the computer, then select *Process Punches From USB Key* from the *Poll / Process* menu at the top menu bar of the CompuTime101 software. On the form that opens click the yellow folder button, navigate to the thumb drive and select the attendance log file, then click the *Process Punch File* button.

- **Note:** Attendance logs are not cleared from the clock automatically. They should be cleared manually after they are processed. (but before employees make new punches at the clock).

To clear the attendance logs at the clock terminal go to **Menu→Options→System Opt→Adv Option→Del AttLogs→OK**

Setting the Clock Time

- The time can be set at the clock in the following menu section: **Menu→Options→System Opt→Date Time** (Use the up/down arrows to move through the fields and press OK to save or ESC to exit)
- **Note:** The hour must be set in 0-23 format (i.e. at 6am the hour should be set to 6, at 6pm the hour should be set to 18)
- The time can also be set from the CompuTime101 software. Open the clock list (select *Edit Clocks* from the *Edit* menu at the top menu bar) and click the *Set Time* button.

Adding Employees in the Software

- Note:** Employees must be manually entered into the software. They can then be uploaded from the software to the clock or manually entered in the clock. The *PIN (Clock) #* in the software must match the PIN number assigned at the clock.
- In the software select *Edit Employees* from the *Edit* menu at the top menu bar
 - *Employee Name*, *Employee #*, *PIN (Clock) #*, and *Department* are required fields
 - Refer to the CT101 User's Guide for more details (from the *Help→Software User Guides* menu at the top menu bar)
 - To assign badge cards and/or upload employees to the clock click the *Assign Badges* button at the bottom of the employee list or select *Manage Employees (XLS Series)* from the *File→Clock Utilities→Pin/Prox/Fingerprint Clocks (XLS Series)* menu.

Upload Employees from the Software to the Clock

You can upload employees from the software if you have the clock connected to the computer via RS232 or Ethernet. Refer to the *Manage Employees* section for more details.

- To assign badge cards and/or upload employees to the clock click the *Assign Badges* button at the bottom of the employee list or select *Manage Employees (XLS Series)* from the *File→Clock Utilities→Pin/Prox/Fingerprint Clocks (XLS Series)* menu.
- Once completed employees will be able to clock in and out with their PIN number (and/or badge card if one is assigned)

Manage Employees from the Software

- Note:** The clock must be connected to the computer via either the RS232 Serial connection or the TCP/IP Ethernet connection.
- Select *Manage Employees* from *File→Clock Utilities→Pin/Prox/Fingerprint Clocks (XLS Series)* software menu
 - **Upload User Data To Clocks:** This will upload the employees listed (name, pin, password, badge, supervisor status) to the clocks. If the employee already exists in the clock their information will be updated, otherwise they will be added to the clocks.
 - **Download User Data From Clocks:** This will download user data (pin, password, badge, supervisor status) from the clocks for employees listed in the software and update their information in the software based on their information in the clocks. Only data for employees that already exist in the software will be downloaded, new employees not already listed in the software will not be added to the software.

Adding an Administrator At The Clock

If no administrators are defined, any user can access the menu. Enrolling at least one admin **w/ SUPERVISOR ACCREDITATION** with a secure PIN or badge card is recommended.

- At the clock in the following menu section: **Menu→User Manage →Enroll Admin**

Enrollment options are:

Reg RFID - The employee will be able to punch in/out with the badge card (badges are optional).

Enroll Pwd - The employee will only be able to punch in/out with a PIN number (the password can be 0 for all users).

Reg Card&Pw - The employee will be able to punch in/out with a PIN number (the password can be 0 for all users) or a badge card (badges are optional).

There are 3 admin levels (set as *Admin Accredit* in the clock menu):

Enroller - Limited rights; *Admin* - Almost all rights; *Supervisor* - All rights

Note: In order to properly use a USB Thumb Drive, the Administrator must have Supervisor rights

Adding Employees At The Clock

- Employees can be added to the clock at the clock terminal in the following menu section: **Menu→User Manage→Enroll User**

Note: If the clock indicates "Admin Affirm" after pressing the Menu button that means the clock menu is protected by an Administrator or Supervisor. At this prompt the admin should enter their PIN or waive their badge to access the clock menu.

Enrollment options are:

Reg RFID - The employee will be able to punch in/out with the badge card (badges are optional).

Enroll Pwd - The employee will only be able to punch in/out with a PIN number (the password can be 0 for all users).

Reg Card&Pw - The employee will be able to punch in/out with a PIN number (the password can be 0 for all users) or a badge card (badges are optional).

Note: It is important to use the employees *PIN (Clock) #* from the software as the *PIN* at the clock.

Note: If the clock indicates "Error Enroll No" after entering the PIN then that number is already assigned to another employee.

Setting Daylight Saving Time

- At the clock in the following menu section: **Menu→Options →System Opt→DLST**

Set DLST=Y to use DLST or N to turn off DLST, Select Mode 1 to set exact dates

Enter DLST = Start Date/Time, Standard = End Date/Time

Start Date/Time is the second Sunday in March, 2:00am (2015 date is 3/8)

End Date/Time is the first Sunday in November, 2:00am (2015 date is 11/1)